CARVER TUBS

CARE & CLEANING INSTRUCTIONS

CARE OF ACRYLIC BATH SURFACE

Do not use abrasive cleaners or solvents on acrylic surfaces. Avoid detergents, disinfectants or cleaning products in aerosol cans.

Wipe out your acrylic bathtub with a soft clothe after use.

If the surface becomes excessively dirty, use a cleaner such as:

- Formula 409 Cleaner
- Soft Scrub, Cleanser
- Mr. Clean_® Cleaner
- Glass Plus Cleaner
- Fantastik_® All Purpose

NOTE: To restore dull or lightly scratched areas, use white automotive polishing compound with a cloth rag. Rub scratches and dull areas intensely. Wipe off residue.

CARE OF WHIRLPOOL SYSTEM

Clean your whirlpool system 2X a month or more, depending on usage.

- 1. Fill the bathtub with warm water to a level at least 2" above the highest jet, or leave water in bathtub after using.
- 2. Add 2 tablespoons of a low-foaming dishwasher detergent and 2-3 cups of household bleach (5-6% sodium hypochlorite) to the water.
- 3. Run whirlpool system for 10 minutes.
- 4. Turn off system and drain water.
- 5. If desired, rinse bathtub surface with water
- 6. Rinse surfaces of jets, faucets, handles, drain etc. and wipe dry with a soft cloth.

CARE OF METAL FINISHES

Water conditions vary accross the county. Chemicals and minerals in the water and air can combine to have an adverse effect on the finishes of your fixtures. We recommend that you rinse away any traces of soap and gently dry with a clean, soft cloth after each use. This care will maintain the high gloss finish of your fixtures.

NOTE: DO NOT USE ABRASIVE CLEANERS OR SOLVENTS